





Typical Performance:



Power De-rating:

Mounting Footprint and Procedure:



The diagram illustrates the mounting procedure. It shows a PCB mounted on a heatsink. Labels include: SOLDER PASTE, PC BOARD HEATSINK, SOLDER FILLED VIA, and SCREW (2 PLS.).


MOUNTING PROCEDURE

1. Solder part in place using 60/40 type solder with Temperature controlled iron (700°F).
2. Drill thermal vias through PCB and fill with solder, such as 60/40 type.
3. To ensure good thermal connectivity to heat sink, drill and tap heatsink and mount PCB board to heat sink using screws.

100200N4Z50-2 (097) Rev A

USA/Canada: (315) 432-8909
 Toll Free: (800) 544-2414
 Europe: +44 2392-232392

Available on Tape and Reel For Pick and Place Manufacturing.



Anaren
 What'll we think of next?™

Mouser Electronics

Authorized Distributor

Click to View Pricing, Inventory, Delivery & Lifecycle Information:

[Anaren:](#)

[100200N4Z50-2](#)